



FLOW HUNTER

**Ultrasonic Open Channel Flow
Measurement**

User Manual

Security Code Default = 1

ECHO Process Instrumentation, Inc.

Ship to: 70 6th Ave.

Mail to: PO Box 800

Shalimar, FL 32579 USA

Phone: 850-609-1300

Fax: 850-651-4777

Email: info@echopi.com

Website: www.echopi.com

CONTENTS


		Page
1.0	Introduction	1
2.0	Operating and Programming	2
	2.1 Run Mode	3
	2.2 Main Menu	4
	2.2.1 Quick Set-up	5
	2.2.2 Set-up relays	9
	2.2.3 Advanced Set-up	10
	2.2.4 Reset Totalizer	12
	2.2.5 Review Set-up	12
3.0	Mounting Instructions	12
	3.1 Transducer Mounting	13
	3.2 Correct Location	14
	3.3 Blanking Distance, Deadband and Safety Procedure	14
APPENDIX A	Primary Measuring Device Types and Dimensions	15
APPENDIX B	Overview of Terminal Connections – Flow Hunter	17
	Connections and Wiring	18
APPENDIX C	All Terminal Connections	19
APPENDIX D	Fault Finding	23

1.0 Introduction

The Flow Hunter instrumentation unit is for use in conjunction with the Xducer 06 non-contact ultrasonic sensor head. The Flow Hunter is a fully programmable open channel flowmeter conforming to US and UK BS3680 calculations for the following channels:

	Range
Model	Liquid
Xducer 06	9.8 – 236 in (0.25 – 6 m)

- V-Notch Weir
- Rectangular Weir
- Rectangular Flume
- 25 Point Table (X,Y)
- Parshall Flume
- Palmer-Bowlus Flume
- Manning Equation (Pipe)



The Flow Hunter measures.

- (i). Volumetric Flow.
- (ii). Total Flow.
- (iii). Distance.
- (iiii). Temperature.

The head measures the time of flight of an ultrasonic pulse to travel from the sensor to the reflecting surface and back to the transducer. This information is transmitted to the instrumentation unit where it is converted into distance and flow information.

distance (**d**) = $\frac{\text{Time of Flight} \times \text{Ultrasonic Velocity}}{2}$

2



Figure 1

The instrumentation unit contains a versatile fully programmable computer which enables a number of processing functions to be carried out. These functions must be configured on first power up of the system. This is known as 'CALIBRATION'.

Programming the unit is simple as the unit is fully menu driven and prompts the user for his preferred choice.

Figure 1. shows the facia layout of the Flow Hunter.


On the front panel facia you will find the LCD display, the **Alarm Set** LED's to the right and the **Programming Keys**.

2.0 Operation and Programming

When installing the Flow Hunter, first install the transducer above the channel as per the instructions in Appendix A.

When power is first applied to the Flow Hunter, it will show the following messages on the LCD display quickly in succession:

This means the Flow Hunter is retrieving the system set-up data from the non-volatile memory.



To program the Flow Hunter, the user is presented with several menus each of which contain numerous options that can be toggled on/off or a numeric value entered.

The menus are all presented on the display as a series of statements which 'cycle round' each time the 'UP' or 'DOWN' push-button is pressed.

To select a particular option, the user has to press the 'ENTER' button when the relevant menu option is displayed.

For all numeric values, the menu statement displays the currently programmed value and allows the user to increase or decrease this value by pressing and holding 'UP' or 'DOWN'. Pressing 'ENTER' will enter the new value into the system and overwrite the old value. If the old value is on the display and the user presses 'ENTER', it has the effect of leaving the number unchanged. The push-buttons automatically repeat if held pressed. The user will see the numbers displayed change slowly at first then increase in speed every few seconds as long as a push-button remains held down. The Flow Hunter also emits a short 'bleep' as an acknowledgement of a key press or when the auto repeat function is in use (default is OFF).

2.1 Run Mode

The Flow Hunter will normally remain in 'Run Mode' displaying the flow information. All the relay outputs are active during this mode.

Depending on the options programmed, pressing the 'UP' or 'DOWN' buttons will scroll the display through the following:

Flow xx.xx GPM Air Temp xx F	Displays the flow rate and air temperature in the Channel. The flow is displayed in Gallons per Minute (GPM) or in other pre-set units and the air temperature in degrees Fahrenheit (°F).
Distance xx.xx ft Air Temp xx F	Displays Distance from the transducer face to the water. If the PMD is empty, then this value is "No Flow Distance".
Total xx.xx Gal Air Temp xx F	Displays the totalized flow up to 999,999.99 Gal. All the information regarding the shape and size of the channel, the head offset etc. are programmed into the Flow Hunter in the calibration menus.
Lost Echo Air Temp xx F	If the Ultrasonic Head should fail to receive echo's from the flow surface, the 'Lost Echo' error message is displayed. If the echo is lost for longer than 20 seconds (user settable), the Lost Echo Relay will then be de-energised. The relay coil is re-energised when the echo returns.
Security Code ? x	To bring the Flow Hunter out of 'Run Mode', press the 'ENTER' button. The unit will then ask for the Security Code number to be entered. The factory pre-set code number is indicated on the front cover of this manual (1) but this can be changed by the authorised user at any time. Use the 'UP' or 'DOWN' buttons to change the displayed number then press 'ENTER' to enter the code. If no code is entered within 12 seconds, the Flow Hunter returns to run mode.
*** ERROR *** INVALID ENTRY	If an incorrect Security Code is entered, this error message is displayed and the unit returns to 'Run Mode'.

2.2 Main Menu

When the correct security code has been entered, the Flow Hunter stops firing the head, turns off all the relays and displays the main menu. This is where the system set-up and calibration parameters can be entered.

The 'UP' and 'DOWN' buttons move the Flow Hunter through the following menu options:

Press 'ENTER' to select the required option.

Main Menu Run Mode ?	Returns the Flow Hunter to 'Run Mode'
Main Menu Quick Setup?	Programs the flumes, weirs, lookup table and the ultrasonic head parameters.
Main Menu Setup Relays?	Programs the relays parameters.
Main Menu Advanced Setup?	Programs the temperature, new password and RS485/RS232 data communications address.
Main Menu Reset Totalizer?	Resets the Totalizer to zero.
Main Menu Review Setup?	Displays the final parameters programmed as a list.

Each of the above menus should be programmed as appropriate when first installing the Flow Hunter.

Definition of Terms:

No flow distance	Distance from sensor face to zero (0) flow point in Primary Measuring Device in inches. Used to calculate the span and fixes the 4mA output value to 0%.
Max. Flow Height	Distance from zero (0) to maximum (100%) HEAD (Level) height in inches corresponding to maximum flow. This is used to calculate the flow span and fixes the 20mA output value to 100%.
Span	Calculated flow span = (max. flow - min flow (zero)). This calculates the Max Flow based on the "Max. Flow Ht" given. This should agree with your flow calculations.
Blanking Distance	Minimum = 9.84 inch (0.25 meter). Should be increased as required to overcome interfering objects / structures between the sensor and maximum flow height. Such interference can lead to a false echo.

2.2.1 Quick Set-up

The “Quick Set-up” menu is where the Primary Measuring Device and the ultrasonic transducer parameters are entered into the Flow Hunter.

Flow Chart: V Notch Weir. For dimensional definitions see Appendix A.

<div style="border: 1px solid black; display: inline-block; padding: 2px 10px;">Program V Notch Weir?</div>												
Select Device:												
V NOTCH WEIR	RECTANGULAR WEIR	RECTANGULAR FLUME	TABLE (X,Y)	PARSHALL FLUME	PALMER-BOWLUS	MANNING (PIPE)						
Select one:												
120 deg	90 deg	60 deg	53 deg & 8 mins	45 deg	30 deg	28 deg & 4 mins	22 deg & 30 mins	EXIT				
Select Units:												
MGD	GPM	GPH	GPD	L/s	m3/s	L/m	m3/m	L/h	m3/h	L/d	m3/d	EXIT
<div style="text-align: right; margin-bottom: 10px;"> No Flow Distance (inches) <i>(Enter the distance from Xducer Face to Zero Flow)</i> <div style="border: 1px solid black; width: 150px; text-align: center; margin: 0 auto;">> XX.XX</div> </div> <div style="text-align: right; margin-bottom: 10px;"> Max Flow Height (inches) <i>(Enter Max Head or Level for Max Flow to be calculated)</i> <div style="border: 1px solid black; width: 150px; text-align: center; margin: 0 auto;">> XX.XX</div> </div> <div style="text-align: right; margin-bottom: 10px;"> Calculated Span xxxx.xx (units) <i>(Span or Max Flow is automatically calculated & shown)</i> <div style="border: 1px solid black; width: 150px; text-align: center; margin: 0 auto;">> ANS = YES, NO or EXIT</div> </div> <div style="text-align: right; margin-bottom: 10px;"> Blanking Distance? <i>(Extend the Blanking Distance to ignore any false echoes)</i> <div style="border: 1px solid black; width: 150px; text-align: center; margin: 0 auto;">> 0.82 ft</div> </div> <div style="text-align: right;"> Accept Data? <i>(YES saves the data to EEPROM)</i> <div style="border: 1px solid black; width: 150px; text-align: center; margin: 0 auto;">> ANS = YES, NO or EXIT</div> </div>												

Flow Chart: Rectangular Weir. For dimensional definitions see Appendix A.

Program Rectangular Weir?															
Select Device:															
V NOTCH WEIR	RECTANGULAR WEIR	RECTANGULAR FLUME	TABLE (X,Y)	PARSHALL FLUME	PALMER-BOWLUS	MANNING (PIPE)									
Select Units:															
MGD	GPM	GPH	GPD	L/s	m3/s	L/m	m3/m	L/h	m3/h	L/d	m3/d	EXIT			
				Sill Width (inches)		<i>(Enter the width or crest length of the Rectangular Weir)</i>									
				> XX.XX											
				Approach Width (inches)		<i>(Enter the width or crest length of the Channel. Suppressed = 0)</i>									
				> XX.XX											
				Sill Height (inches)		<i>(Enter the height of the Rectangular Weir)</i>									
				> XX.XX											
				No Flow Distance (inches)		<i>(Enter the distance from Xducer Face to Zero Flow)</i>									
				> XX.XX											
				Max Flow Height (inches)		<i>(Enter Max Head or Level for Max Flow to be calculated)</i>									
				> XX.XX											
				Calculated Span XXXX.XX (units)		<i>(Span or Max Flow is automatically calculated & shown)</i>									
				> ANS = YES, NO or EXIT											
				Blanking Distance?		<i>(Extend the Blanking Distance to ignore any false echoes)</i>									
				> 0.82 ft											
				Accept Data?		<i>(YES saves the data to EEPROM)</i>									
				> ANS = YES, NO or EXIT											

Flow Chart: Rectangular Flume. For dimensional definitions see Appendix A.

Program Rectangular Flume?															
Select Device:															
V NOTCH WEIR	RECTANGULAR WEIR	RECTANGULAR FLUME	TABLE (X,Y)	PARSHALL FLUME	PALMER-BOWLUS	MANNING (PIPE)									
Select Units:															
MGD	GPM	GPH	GPD	L/s	m3/s	L/m	m3/m	L/h	m3/h	L/d	m3/d	EXIT			
				Throat Width (inches)		<i>(Enter the throat or narrowest width of the Rectangular Flume)</i>									
				> XX.XX											
				Channel Width (inches)		<i>(Enter the width of the Approach Channel before the Flume)</i>									
				> XX.XX											
				Throat Length (inches)		<i>(Enter the Throat or narrowest section Length)</i>									
				> XX.XX											
				No Flow Distance (inches)		<i>(Enter the distance from Xducer Face to Zero Flow)</i>									
				> XX.XX											
				Max Flow Height (inches)		<i>(Enter Max Head or Level for Max Flow to be calculated)</i>									
				> XX.XX											
				Calculated Span XXXX.XX (units)		<i>(Span or Max Flow is automatically calculated & shown)</i>									
				> ANS = YES, NO or EXIT											
				Blanking Distance?		<i>(Extend the Blanking Distance to ignore any false echoes)</i>									
				> 0.82 ft											
				Accept Data?		<i>(YES saves the data to EEPROM)</i>									
				> ANS = YES, NO or EXIT											

Flow Chart: X,Y Table.

<div style="border: 1px solid black; display: inline-block; padding: 2px 10px;">Program Table?</div>													
Select Device:													
V NOTCH WEIR	RECTANGULAR WEIR	RECTANGULAR FLUME	TABLE (X,Y)	PARSHALL FLUME	PALMER-BOWLUS	MANNING (PIPE)							
Select Units:													
MGD	GPM	GPH	GPD	L/s	m3/s	L/m	m3/m	L/h	m3/h	L/d	m3/d	EXIT	
<div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%;"> <p style="text-align: center;">No Flow Distance (inches)</p> <div style="border: 1px solid black; padding: 2px; text-align: center;">> xx.xx</div> </div> <div style="width: 50%; font-size: small;">(Enter the distance from Xducer Face to Zero Flow)</div> </div> <div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%;"> <p style="text-align: center;">Max Flow Height (inches)</p> <div style="border: 1px solid black; padding: 2px; text-align: center;">> xx.xx</div> </div> <div style="width: 50%; font-size: small;">(Enter Max Head or Level for Max Flow to be calculated)</div> </div> <div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%;"> <p style="text-align: center;"># table entries</p> <div style="border: 1px solid black; padding: 2px; text-align: center;">> xx</div> </div> <div style="width: 50%; font-size: small;">(Enter the number of X,Y points to plot Head, Flow)</div> </div> <p style="font-size: x-small; margin-top: 10px;">Ignore Zero and Max Flow, it has been inputed automatically. # Points/100 and Enter Flowrate (UOM = Units of Measurement) for each Point n proportionally.</p> <div style="display: flex; justify-content: space-around; margin-bottom: 10px;"> <div style="width: 45%; text-align: center; font-size: x-small;">Point (1) ? UOM</div> <div style="border: 1px solid black; padding: 2px; text-align: center;">> xx.xx</div> <div style="width: 45%; text-align: center; font-size: x-small;">Point (n) ? UOM</div> <div style="border: 1px solid black; padding: 2px; text-align: center;">> xx.xx</div> </div> <div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%; text-align: center; font-size: x-small;">Accept Data?</div> <div style="width: 50%; font-size: x-small;">(YES saves the data to EEPROM)</div> </div> <div style="border: 1px solid black; padding: 2px; text-align: center; margin-bottom: 10px;">> ANS = YES, NO or EXIT</div> <div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%; text-align: center; font-size: x-small;">Blanking Distance?</div> <div style="width: 50%; font-size: x-small;">(Extend the Blanking Distance to ignore any false echoes)</div> </div> <div style="border: 1px solid black; padding: 2px; text-align: center; margin-bottom: 10px;">> 0.82 ft</div> <div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%; text-align: center; font-size: x-small;">Accept Data?</div> <div style="width: 50%; font-size: x-small;">(YES saves the data to EEPROM)</div> </div> <div style="border: 1px solid black; padding: 2px; text-align: center;">> ANS = YES, NO or EXIT</div>													

Flow Chart: Parshall Flume. For dimensional definitions see Appendix A.

<div style="border: 1px solid black; display: inline-block; padding: 2px 10px;">Program Parshall Flume?</div>													
Select Device:													
V NOTCH WEIR	RECTANGULAR WEIR	RECTANGULAR FLUME	TABLE (X,Y)	PARSHALL FLUME	PALMER-BOWLUS	MANNING (PIPE)							
Select Size													
<div style="border: 1px solid black; display: inline-block; padding: 2px 10px;">> xx</div> <div style="font-size: x-small; margin-left: 10px;">(Select Size: 1", 2", 3", 6", 9", 12", 1.5', 2', 3', 4', 5', 6', 8', 12')</div>													
Select Units:													
MGD	GPM	GPH	GPD	L/s	m3/s	L/m	m3/m	L/h	m3/h	L/d	m3/d	EXIT	
<div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%;"> <p style="text-align: center;">No Flow Distance (inches)</p> <div style="border: 1px solid black; padding: 2px; text-align: center;">> xx.xx</div> </div> <div style="width: 50%; font-size: small;">(Enter the distance from Xducer Face to Zero Flow)</div> </div> <div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%;"> <p style="text-align: center;">Max Flow Height (inches)</p> <div style="border: 1px solid black; padding: 2px; text-align: center;">> xx.xx</div> </div> <div style="width: 50%; font-size: small;">(Enter Max Head or Level for Max Flow to be calculated)</div> </div> <div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%;"> <p style="text-align: center;">Calculated Span xxx.xx (units)</p> <div style="border: 1px solid black; padding: 2px; text-align: center;">> ANS = YES, NO or EXIT</div> </div> <div style="width: 50%; font-size: small;">(Span or Max Flow is automatically calculated & shown)</div> </div> <div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%; text-align: center; font-size: x-small;">Blanking Distance?</div> <div style="width: 50%; font-size: x-small;">(Extend the Blanking Distance to ignore any false echoes)</div> </div> <div style="border: 1px solid black; padding: 2px; text-align: center; margin-bottom: 10px;">> 0.82 ft</div> <div style="display: flex; justify-content: space-between; margin-bottom: 10px;"> <div style="width: 45%; text-align: center; font-size: x-small;">Accept Data?</div> <div style="width: 50%; font-size: x-small;">(YES saves the data to EEPROM)</div> </div> <div style="border: 1px solid black; padding: 2px; text-align: center;">> ANS = YES, NO or EXIT</div>													

Flow Chart: Palmer-Bowlus Flume. For dimensional definitions see Appendix A.

Program Palmer-Bowlus Flume?												
Select Device:												
V NOTCH WEIR	RECTANGULAR WEIR	RECTANGULAR FLUME	TABLE (X,Y)	PARSHALL FLUME	PALMER-BOWLUS	MANNING (PIPE)						
<div style="display: flex; justify-content: space-between;"> <div> Select Size <input style="width: 150px;" type="text" value=" > xx"/> </div> <div style="font-size: small;"> <i>(Select Size: 4", 6", 8", 10", 12", 15", 18", 21", 24", 27", 30")</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Select Units: <div style="display: flex; justify-content: space-around; font-size: x-small;"> MGDGPMGPHGPDL/sm3/sL/mm3/mL/hm3/hL/dm3/dEXIT </div> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> No Flow Distance (inches) <input style="width: 150px;" type="text" value=" > xx.xx"/> </div> <div style="font-size: x-small;"> <i>(Enter the distance from Xducer Face to Zero Flow)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Max Flow Height (inches) <input style="width: 150px;" type="text" value=" > xx.xx"/> </div> <div style="font-size: x-small;"> <i>(Enter Max Head or Level for Max Flow to be calculated)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Calculated Span xxx.xx (units) <input style="width: 150px;" type="text" value=" > ANS = YES, NO or EXIT"/> </div> <div style="font-size: x-small;"> <i>(Span or Max Flow is automatically calculated & shown)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Blanking Distance? <input style="width: 150px;" type="text" value=" > 0.82 ft"/> </div> <div style="font-size: x-small;"> <i>(Extend the Blanking Distance to ignore any false echoes)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Accept Data? <input style="width: 150px;" type="text" value=" > ANS = YES, NO or EXIT"/> </div> <div style="font-size: x-small;"> <i>(YES saves the data to EEPROM)</i> </div> </div>												

Flow Chart: Manning Equation (PIPE).

Program Manning Equation (Pipe)?												
Select Device:												
V NOTCH WEIR	RECTANGULAR WEIR	RECTANGULAR FLUME	TABLE (X,Y)	PARSHALL FLUME	PALMER-BOWLUS	MANNING (PIPE)						
<div style="display: flex; justify-content: space-between;"> <div> Inner Diameter (inches) <input style="width: 150px;" type="text" value=" > xx.xx"/> </div> <div style="font-size: x-small;"> <i>(Enter the Pipe (Inlet - Outlet) Vertical Ht & Horizontal Length)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Slope ($\Delta Y / \Delta X$) <input style="width: 150px;" type="text" value=" > x.xx"/> </div> <div style="font-size: x-small;"> <i>(Enter the Pipe (Inlet - Outlet) Vertical Ht & Horizontal Length)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Roughness <input style="width: 150px;" type="text" value=" > x.xx"/> </div> <div style="font-size: x-small;"> <i>(Enter the Manning Coefficient of Roughness for the Pipe Liner)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Select Units: <div style="display: flex; justify-content: space-around; font-size: x-small;"> MGDGPMGPHGPDL/sm3/sL/mm3/mL/hm3/hL/dm3/dEXIT </div> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> No Flow Distance (inches) <input style="width: 150px;" type="text" value=" > xx.xx"/> </div> <div style="font-size: x-small;"> <i>(Enter the distance from Xducer Face to Zero Flow)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Max Flow Height (inches) <input style="width: 150px;" type="text" value=" > xx.xx"/> </div> <div style="font-size: x-small;"> <i>(Enter Max Head or Level for Max Flow to be calculated)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Calculated Span xxx.xx (units) <input style="width: 150px;" type="text" value=" > ANS = YES, NO or EXIT"/> </div> <div style="font-size: x-small;"> <i>(Span or Max Flow is automatically calculated & shown)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Blanking Distance? <input style="width: 150px;" type="text" value=" > 0.82 ft"/> </div> <div style="font-size: x-small;"> <i>(Extend the Blanking Distance to ignore any false echoes)</i> </div> </div>												
<div style="display: flex; justify-content: space-between;"> <div> Accept Data? <input style="width: 150px;" type="text" value=" > ANS = YES, NO or EXIT"/> </div> <div style="font-size: x-small;"> <i>(YES saves the data to EEPROM)</i> </div> </div>												

2.2.2 Setup Relays


The 'Set-up relay' menu is where the programmable relay information is entered into the Flow Hunter.

The relays can be programmed via the 'Set-up relay' option of the main menu. There are 4 relays on the Flow Hunter of both **Normally Open** (NO) and **Normally Closed** (NC) configuration.

The 4 relays on the ECHO Flow Hunter can be programmed individually to switch on the following choices:

- | | | |
|----------------|----|--|
| Flow | 1. | High flow LEVEL alarm based on a maximum level value |
| | 2. | Low flow LEVEL alarm based on a minimum level value |
| Sampler | 3. | Pulsed every xxx ft ³ |


Once you have selected 'Set-up relay' you may cycle through these choices until you select one of them. You will then be asked to enter the appropriate values.



2.2.3 Advanced Set-up

In this menu, the settings of the unit address (RS485 only), temperature compensation, operator security code and Lost Signal settings can be changed.

The menu structure is displayed below:



4 - 20mA Output

The unit is provided with a 4-20mA isolated output as standard.

The 4-20mA output is automatically scaled to the selected span (max flow height) you have programmed.

e.g. If you have programmed a span of 50 GPM then the unit will output 4mA as Zero (0) flow and 20mA as max. flow (50 GPM)

Lost Echo :

The Lost Echo function is signalled on the 4-20mA output as 0mA (i.e Open Circuit). To ensure the unit fails to a safe condition under power loss or malfunction the lost echo function must always be used.

NOTE :

The velocity of sound changes by 0.18% per °C change in temperatures.

2.2.4 Reset Totalizer

It will display “Clear Totalizer, Change ?” Select “YES” and press ENTER password “120”.

It will then show “Totalizer Clear”.

.

2.2.4 Display Set-up

In this menu, the settings of the unit can be confirmed. Press any key to scroll through the display (it will loop back to Review Setup at the end).

This is a useful way to view that all programmed parameters have been correctly entered.

3.0 Mounting

Transducer Location

Correct positioning of the sensor is vital if accurate results are to be obtained. A basic error in installing the sensor will cause inaccuracies in all other aspects of flow metering. The sensor must be held rigidly over the channel and directed towards the liquid face.

- i. Locate the sensor at least 18 inches above the maximum level.
- ii. Ensure that the ultrasonic beam has a clear path to its target and is not going to strike objects on the wall of the channel.
- iii. Fix the sensor in a vertical position. Hand-tighten the transducer to avoid ringing in the winter.
- iv. Try to avoid situations where the temperature sensor is exposed to sunlight especially at dawn and evening.
- v. In the event of the transducer being exposed to prolonged strong sunlight a simple heat-shield erected above the sensor will ensure correct temperature compensation in the most severe conditions. A suitable shield is available from ECHO PI.

3.1 Transducer Mounting

It is recommended that the Ultrasonic transducer is mounted on a bracket above the channel to overcome the deadband of the transducer as follows :

Xducer 06 - Deadband = 9.84" (0.25m)

This arrangement allows the transducer to cover the full operating range.

The top of the sensor is provided with a 1" NPT thread allowing it to be bolted to a suitable bracket.

When tightening the transducer securing screw it is important that the natural turning moment of the transducer is resisted with a suitable open-ended spanner. Failure to observe this precaution could result in the damage of the transducer. Hand-tight ONLY.

UNDER NO CIRCUMSTANCE SHOULD THE BODY OF THE TRANSDUCER BE CLAMPED, EITHER WHILE IT IS BEING SECURED OR WHEN IN USE.

NOTES


- A. Support and restrain sensor cables to avoid damage.
- B. Route sensor cables away from power cables and other sources of interference.
- C. Where cables pass through a junction box, maintain continuity of the screen.

NOTE

You will have been provided with the correct/requested length of transducer cable for your application-should you wish to extend this cable length it should only be done by adding to the existing length through an IP68 gland.

Always use the nut provided and insert the damping washers. Do not over-tighten the nut as ringing may occur.

Use a spirit level or a plumb line to ensure the transducer is aligned "normal" to the reflecting surface.




3.2 Correct Location

The transducers should be placed such that the ultrasonic beam does not reflect from interfering structures during its flight path.

The beam spread for the ultrasonic wave as it travels from the transducer is 6 degrees.

Ensure that at the maximum distance to be measured, the beam does not collide with interfering structures.

3.3 Blanking Distance, Deadband and Safety Procedure



There may be instances where obstructions in the channel give rise to false echoes. If such obstructions are above the maximum level to be measured then they may be gated out by instructing the computer to ignore any return echo in the flight path up to such an obstruction. This is performed in the calibration mode by programming in a blanking distance. The blanking distance programmed should be the distance from the transducer to 9.8 inches (0.25m).


All ultrasonic transducers have a blind area called the "deadband". Within this area the sensor cannot detect the true echo. This should be borne in mind when setting up the unit since if you allow your liquid to fill into this area the instrumentation unit will not return lost echo but give an erroneous reading which relates to a multiple echo, which in the time base is perceived to be outside the deadband region.

In order to prevent this occurrence you should always assign one of the relays to a high alarm condition.. The level of this high alarm must be below the dead band zone which is given in inches in the Quick Setup menu for each head type. It is recommended that you make this alarm setting equal to the distance of the deadband plus 20%. For example an Xducer 06 head with a deadband of 9.8 inches should have a high level alarm set at a distance of 12 inches from the surface of the transducer head.

A safety margin of 2 inches above the blanking zone should be sufficient for most applications.


Appendix A: Channel types and dimensions

Transducer Location For Rectangular Flumes







Transducer Location For Parshall Flumes

Mount the transducer $\frac{2}{3} L$ upstream.



Transducer Location For Weirs



Appendix B: Overview of Terminal Connections for Flow Hunter

All connections to the unit are located on the rear section of the unit housing. The Ultrasonic Transducer has been supplied with 10m standard cable unless ordered with longer length with the wires labelled (see Connections and Wiring). A weatherproof IP68 gland must be used to make any termination's or when extending cable length. Access into the transducer will invalidate the guarantee.

All wiring must be to the latest IEEE regulations.

Power Connections

The unit can be powered from mains 110/230VAC (24VDC is ordered separately). The details of the Power connections are given in the diagram below.

The Power drawn is 5 Watts.

Fuse Rating : 20mm 1A Anti-surge

Relay Connections

There are 4 programmable relays. These relays have both normally open (NO) and normally closed (NC) contacts so that they can be used in any configuration.

The ratings for the relays are as follows:

Max. Switched current and voltage	1A @ 24VDC
Electrical life at full load	min. 8×10^4 operations
Mechanical life	min. 5×10^6 operations

Communications

The RS232 is factory set to:-

8 Data bits
1 Start bit
1 Stop bit
No Parity

The data is fixed at 9600 baud.

The information format is an ASCII string of characters that is terminated by a ZERO character before the information is repeated.

Connections and Wiring

<u>Relay 1</u>		
	RL1	
	Common	COM
	Normally Closed	NC
	Normally Open	NO
<u>Relay 2</u>		
	RL2	
	Common	COM
	Normally Closed	NC
	Normally Open	NO
<u>4-20mA Isolated</u>		
	+Ve (+)	
	0V (-)	
<u>Transducer</u>		
	SCR	Shield
	RET	RED
	TR	BLACK
	TM+	WHITE
	TM-	GREEN
<u>Supply</u>		
	L	LIVE
	N	NEUTRAL
	E	EARTH (Ground)

Relays	RL 1	COM	
		N.C	
		N.O	
	RLn	COM	
		N.C	
		N.O	
Analog	4-20mA	+VE	
		0V	
Xducer	+VE	(empty)	
	0V	(empty)	
	SCR (SHIELD)		
	RET	RED	
	TR	BLACK	
	TM+	WHITE	
Power Supply		TM- GREEN	
		L	
		N	
		E	

Cable type: 4 Conductor Cable, Shielded. Max. current per Core 1A. Max. Temp 70 deg C.

Transducer Remote Driver

If the transducer cable exceeds 50m (150'), a remote driver interface box is required for extended runs. The connection to this driver is via a 6 core cable type Defence Standard 61-12, Sub miniature Cable Specification 16-2-6C. See page 22. Connection details are printed on the rear of the units

Appendix C: All Terminal Connections for Flow Hunter

All connections to the unit are located in the lower section of the unit housing. Access to this area does not invalidate the guarantee.

All wiring must be to the latest IEEE regulations.

The unit supply voltage must be provided via a double pole spur.


Mains Connection

The units are factory set to operate from either 115V or 230V, 50Hz mains. This is indicated on the rating label adhered to the unit.

Fuse Rating :- 20mm 250V, 250mA Anti-Surge.

The diagram shows the connections for Live, Neutral and Earth.

Printed Circuit Board (PCB)



Relay Connections

There are 4 programmable relays and 1 lost echo relay that are available to external circuitry. These relays have both normally open (NO) and normally closed (NC) contacts so that they can be used in any configuration.


The ratings for the relays are as follows:

Max. Switched current	5A
Max. Switched voltage	30V DC / 250V AC
Electrical life at full load	min. 8×10^4 operations
Mechanical life	min. 10^7 operations



The connections for the relays are shown below

Printed Circuit Board (PCB)



Lost Echo Relay :

Normal procedure for the lost echo relay would be to connect the NO and COM terminals since this relay is energised during normal operation of the transducers.


On a lost echo condition the relay is de-energised.

The L.E relay should be used as a fail-safe relay connected in series with the other 4

programmable relays. This ensures that all power to external equipment is removed when the

Flow Hunter is not in the 'Run Mode' or if there is a power failure to the unit. If the L.E relay is

not used, any equipment connected to the NC connections of the other relays will run if power is removed because these relays will de-energise. i.e. NC contact is made.



Transducer Connections from Enclosure to Remote Transducer Driver J-Box (long cable run only)

The connections for the ultrasonic head is shown below. Normally the head uses four wires, red, green, white and white as indicated in the table below.

The 'THERMISTOR' connections relate to the temperature sensor associated with the ultrasonic head.

<u>Connection</u>	<u>Head Cable Color</u>	<u>Printed Circuit Board (PCB)</u>
+VE	Red	<div> <div>CTR10</div> <div>CTR11</div> </div>
0V	Green	
SCR	Screen	
RTN	Blue	
TR	Yellow	
Thermistor +	White	
Thermistor -	Black	

Note
Ensure connector block from transducer is correctly wired

Transducer Connections with Internal Transducer Driver (Standard)

<u>Connection</u>	<u>Head Cable Color</u>	<u>Printed Circuit Board (PCB)</u>
+VE	No Connection	<div> <div>CTR10</div> <div>CTR11</div> </div>
0V	No Connection	
SCR	Shield	
RET	Red	
TR	Black	
Thermistor + (TM+)	White (Temperature sensor)	
Thermistor - (TM-)	Green (Temperature sensor)	

Communications

The RS232/422 is factory set to:

The diagram shows the CTR14 PCB with the following pin headers and functions:

- 8 Data bits**
- 1 Start bit**
- 1 Stop bit**
- No Parity**

The board is labeled **Printed Circuit Board (PCB)** and **CTR14**.

The pin headers are labeled as follows:

- RS232 TX / RS422TXA**
- RS232 RX / RS422 RXA**
- GND (0V)**
- RS422 TXB**
- RS422 RXB**

A **Printer** is connected to the RS422 TXB and RXB pins.

The data rate is fixed at 9600 baud. The information format is an ASCII string of characters that is terminated by a ZERO character before the information is repeated.


The connections are as shown.

Low Voltage Power Connections

The unit can be powered from either 24 Volts AC or 24 Volts DC. The details of the low Voltage power connections are:-

Printed Circuit Board (PCB)

CTR4



24 V AC / +24V DC
24 V AC / 0V DC

THIS MUST BE FACTORY SET

4 - 20mA Output

The unit can be provided with a 4-20mA output option.

The terminal connections for this are shown below:

Printed Circuit Board (PCB)


CTR12




4 - 20mA Out
Isolated GND

Installation With Remote Driver Electronics

Note:
If you have specified the distance from the instrument to the transducer less than 50m, the instrument supplied will have an integral transducer driver board built in.



Wiring Connection For Remote Transducer Driver



<u>CONNECTION</u>	<u>ID</u>
<u>To Instrument</u>	
TH1	- Instrument White : Temperature sensor
TH2	- Instrument Black : Temperature sensor
TRIG	- Instrument Yellow
RET	- Instrument Blue
GND	- Instrument Green
+15V	- Instrument Red
<u>From Transducer</u>	
X1	- Transducer Red
SCN	- Transducer Screen
X2	- Transducer Black
TH1	- Transducer Green : Temperature sensor
TH2	- Transducer White : Temperature sensor

Cable Type and Cable Installation:

From Instrument to Remote Transducer Drive Electronics: Defence Standard, 61-12 Sub-miniature Cable Specification 16-2-6C. It is essential to use this cable type or cable with cores in the same orientation. Failure to do so will cause fluctuating readings due to cross coupling of transmit and receive signals.

From Transducer To Remote Transducer Drive Electronics : 4 Core Screened twisted Pair with Integral Drain Wire And Individually Screened. Impedance 54 ohms, Capacitance core/core 115pF.

General Notes: Where multiple sensors are connected to the instrumentation ensure that the cables are kept at least 12 inches apart to prevent magnetic coupling.. Always ensure grounds and screens are connected.

Appendix D: Fault Finding

Ringing


When in the transmit mode, ultrasonic transducers convert electrical energy into mechanical energy causing the transducer to vibrate, like a loudspeaker. Most of this energy is converted into an ultrasonic acoustic wave but some is transmitted into the transducer housing. This is analogous to striking a bell whereby you hear a sound but also you can observe the bell mechanically "RINGING". If this is excessive it will take a long time to die away and can still be present when the return echo arrives back at the transducer. In such cases the transducer cannot recognize the returning echo and as a result the system cannot calculate range.

Ring

ing can be recognised by a higher than expected level indicated. To reduce ring

ing always use gaskets and never over-tighten bolts. Hand tighten the transducer. Increasing the blanking distance beyond the ring

No Display showing FMP not firing:



Check supply to FMP.

Carefully unscrew the four screws and remove fascia label plate and check fuse, if blown replace with 1.0 Amp anti-surge fuse.

Display shows higher than expected reading:

Ring

ing of transducer - check bolts have not been over-tightened and the damping washer is fitted.

False echo from object in transmission path - reposition transducer or extend blanking distance.

Velocity of sound not set correctly - re-program to correct temperature setting or install new temperature sensor.

Display shows lost echo:

Transducer incorrectly wired - check wiring diagrams against installation.

Poor wiring connection - ensure all wires are securely connected.

Poor Earth - meter earth connection and rewire if necessary.

Liquid level has entered the blanking zone and / or the near field - reduce level until reading returns (see Section 3.2)

Stilling well has curved bottom and is empty - this will cause the ultrasonic signal to bounce around the well arriving back at the transducer outside its permissible time for the set height - ensure transducer is positioned as central as possible and the well always has liquid present below the transducer.

Foam present - foam absorbs ultrasound - reposition transducer away from foam. Placing in a stand (stilling pipe) pipe will suffice provided foam does not penetrate the pipe.

Temperature thermals - foam occasionally present; use stand pipe

Display shows periodic lost echo:

Large undulating surface associated with very turbulent liquids causing unfavourable reflecting surface; reposition transducer above flattest surface or in the case of liquids use a stilling pipe.

Transducer not mounted to the normal reflecting surface - using a spirit level realign transducer.

Ultrasonic beam occasionally catches edge of weir tank or flume; Lower transducer or place in stilling pipe.

Temperature fluctuations:

Damage to thermocouple - using a multimeter check the resistance of the thermocouple. It should read between 400 ohms and 100K ohms depending on the temperature being measured. (10K ohms @ 25 deg. C)

Display fluctuates :

Periodic lost echo - check all factors above.

Totalizer gives lower than expected readings

Low flow rate operating outside the BS standards. Increase flow rate through weir.